

# Florsheim

SHOE COMPANY



SPRING 2024 CATALOG





**CROSSOVER**  
Moc Toe  
Slip On







CASUAL



**SOCIAL**  
Lace to Toe  
Sneaker







## Satellite Perf Lace Up Sneaker | COMFORTECH

14423



221



001



410

**221 Cognac | 001 Black | 410 Navy**

Perfed smooth leather with mesh upper, comfortable Lycra and mesh linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, shock absorbing EVA midsole for utmost comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14

## Satellite Knit Elastic Lace Slip On Sneaker | COMFORTECH 14422



020



001



108



410

**020 Gray | 001 Black | 108 Ice | 410 Navy**

Knit textile with nubuck upper, comfortable Lycra textile linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, shock absorbing EVA midsole for utmost comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14

## Social Lace to Toe Sneaker | COMFORTECH

14427



100



001



111



229



410

**100 White | 001 Black | 111 Black & White | 229 Cognac Smooth | 410 Navy**

Smooth leather upper, breathable mesh linings for additional comfort, fully cushioned Comfortech footbed with sheepskin leather cover and molded EVA for all-day comfort, durable EVA outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 8-11, 12, 13

## Social Plain Toe Slip On Sneaker | COMFORTECH

14428



229



111

**229 Cognac Smooth | 111 Black & White**

Smooth leather upper, breathable mesh linings for additional comfort, fully cushioned Comfortech footbed with sheepskin leather cover and molded EVA for all-day comfort, durable EVA outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 8-11, 12, 13

## Heist Lace to Toe Sneaker | COMFORTECH

14352



221



001



111

### 221 Cognac Smooth | 001 Black Smooth/Suede | 111 White Smooth/Suede

Leather or leather with suede upper, breathable mesh linings, fully cushioned, removable Comfortech footbed with OrthoLite® high rebound foam for long-term wearability, shock absorbing EVA midsole for utmost comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Heist Knit Lace to Toe Sneaker | COMFORTECH

14354



020



001



125



410

### 020 Gray | 001 Black | 125 Oyster | 410 Navy

Knit textile with smooth leather and suede upper, breathable mesh linings, fully cushioned, removable Comfortech footbed with OrthoLite® high rebound foam for long-term wearability, shock absorbing EVA midsole for utmost comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Venture Knit Plain Toe Lace Up Sneaker | COMFORTECH

14315



001



020



051



410

### 001 Black | 020 Gray | 051 Mushroom | 410 Navy

Knit textile with nubuck upper, comfortable Lycra textile linings, fully cushioned Comfortech footbed for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole.

M 7-12, 13, 14 W 7-11, 12, 13

## Crossover Lace to Toe Sneaker | COMFORTECH

14307



051



001



100



221



410

**051 Mushroom Crazy Horse | 001 Black | 100 White | 221 Cognac | 410 Navy**

Soft leather upper, breathable mesh linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, SupaCush EVA midsole for added cushioning and rebound responsiveness, durable rubber outsole with Flexsole Technology for out-of-the-box comfort, slip-resisting and non-marking.

M 7-12, 13, 14 W 7-11, 12, 13

## Crossover Canvas Elastic Slip On | COMFORTECH

14405



340



001



050



410

**340 Green Multi | 001 Black | 050 Light Grey | 410 Navy**

Stretch canvas with mesh and suede upper, breathable stretch mesh linings for additional comfort, fully cushioned Comfortech footbed with molded EVA for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Crossover Moc Toe Slip On | COMFORTECH

14421



051



416

**051 Mushroom Nubuck | 416 Navy Nubuck**

Milled nubuck with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15

## Crossover Double Gore Slip On | COMFORTECH

14425



051



416

**051 Mushroom Nubuck | 416 Navy Nubuck**

Milled nubuck with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13



## Crossover Moc Toe Elastic Lace Boat Shoe | COMFORTECH 14426



416



051



246

### 416 Navy Nubuck | 051 Mushroom Nubuck | 246 Brown Nubuck

Milled nubuck with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Lakeside Moc Toe Oxford

13157



200



275

### 200 Brown Nubuck | 275 Stone Crazy Horse

Nubuck with milled leather or crazy horse with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned EVA footbed for all day-comfort, rubber outsole offers durability, traction, and comfort.

(275) M 7-12, 13, 14 W 7-11, 12, 13, 14 XW 7-11, 12, 13

(200) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15 XW 7-11, 12, 13

## Lakeside Moc Toe Slip On

13158



200



275

### 200 Brown Nubuck | 275 Stone Crazy Horse

Nubuck with milled leather or crazy horse with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned EVA footbed for all day-comfort, rubber outsole offers durability, traction, and comfort.

(200) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15 XW 7-11, 12, 13

(275) M 7-12, 13, 14 W 7-11, 12, 13, 14 XW 7-11, 12, 13

## Lakeside Canvas Moc Toe Slip On

13401



410



001



020

### 410 Navy | 001 Black | 020 Gray

Canvas with nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned EVA footbed for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13 XW 8-11, 12, 13



## Motor Moc Toe Penny Driver | COMFORTECH

13411



221



001



200

### 221 Cognac | 001 Black | 200 Brown

Weave print leather with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Motor Moc Toe Bit Driver | COMFORTECH

13410



245



001



200



221

### 245 Brown Suede | 001 Black Smooth | 200 Brown Smooth | 221 Cognac Smooth

Smooth leather or suede with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Motor Moc Toe Venetian Driver | COMFORTECH

13412



215



001



221



414

### 215 Brown Crazy Horse | 001 Black | 221 Cognac | 414 Navy Suede

Smooth leather or suede with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, durable rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Atlantic Moc Toe Boat Shoe

13367



202



221



410

### 202 Chocolate Smooth | 221 Cognac Smooth | 410 Navy Nubuck

Leather or nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with OrthoLite® high rebound foam for all-day comfort, lightweight and durable EVA sole.

M 7-12, 13, 14 W 7-11, 12, 13



## Tread Lite River Sandal | COMFORTECH

14362



215



001



200



260

**215 Brown Crazy Horse | 001 Black Nubuck | 200 Brown | 260 Taupe Nubuck**

Knit textile with nubuck or knit textile with casual leather upper, breathable mesh linings for additional comfort, fully cushioned Comfortech footbed with molded PU for all-day comfort, Rebound EVA midsole for added cushioning and rebound responsiveness, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-14 (Whole sizes only) W 7-13 (Whole sizes only)

## Tread Lite Thong Sandal | COMFORTECH

14363



215



001



260



410

**215 Brown Crazy Horse | 001 Black Nubuck | 260 Taupe Nubuck | 410 Navy Nubuck**

Nubuck with knit textile or casual leather with knit textile upper, breathable mesh linings, fully cushioned Comfortech footbed with molded PU for all-day comfort, Rebound EVA midsole for added cushioning and rebound responsiveness, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-14 (Whole sizes only) W 7-13 (Whole sizes only)

## Venture Fisherman Sandal | COMFORTECH

14320



215



010

**215 Brown Crazy Horse | 010 Black Crazy Horse**

Casual leather upper, breathable mesh linings, fully cushioned Comfortech footbed for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole.

M 7-14 (Whole sizes only) W 7-13 (Whole sizes only)



# DRESS



**RUCCI**  
Weave Cap Toe  
Oxford

## Vibe Wingtip Oxford | COMFORTECH

14417



229



009



221

### 229 Cognac Smooth | 009 Black Smooth | 221 Cognac

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Vibe Plain Toe Oxford | COMFORTECH

14418



215



009



229

### 215 Brown Crazy Horse | 009 Black Smooth | 229 Cognac Smooth

Smooth leather or waxed nubuck upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Vibe Knit Plain Toe Oxford | COMFORTECH

14420



410



001



020

### 410 Navy | 001 Black | 020 Gray

Knit textile with nubuck and smooth leather upper, unlined shoe, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Vibe Canvas Plain Toe Oxford | COMFORTECH

14419



020



001



260



400

### 020 Gray | 001 Black | 260 Taupe | 400 Blue

Canvas with smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13



## Norwalk Plain Toe Oxford | COMFORTECH

13369



229



009



010



215



222

**229 Cognac Smooth | 009 Black Multi | 010 Black Crazy Horse | 215 Brown Crazy Horse | 222 Cognac Milled**

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned removeable Comfortech footbed with molded EVA for all-day comfort, flexible TPU midsole for enhanced comfort, with Flexsole Technology for out-of-the-box comfort, lightweight TPU outsole.

(009, 222) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14

(010, 215, 229) M 7-12, 13, 14, 15, 16 W 7-11, 12, 13, 14, 15

## Norwalk Cap Toe Oxford | COMFORTECH

13368



222



010



215

**222 Cognac Milled | 010 Black Crazy Horse | 215 Brown Crazy Horse**

Casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned removeable Comfortech footbed with molded EVA for all-day comfort, flexible TPU midsole for enhanced comfort, with Flexsole Technology for out-of-the-box comfort, lightweight TPU outsole.

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14

## Norwalk Moc Toe Slip On | COMFORTECH

13404



001



221

**001 Black | 221 Cognac**

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned removeable Comfortech footbed with molded EVA for all-day comfort, flexible TPU midsole for enhanced comfort, with Flexsole Technology for out-of-the-box comfort, lightweight TPU outsole.

M 7-12, 13, 14 W 7-11, 12, 13



215

## Norwalk Plain Toe Lace Up Boot | COMFORTECH

13376



006



222

### 215 Brown Crazy Horse | 006 Black Nubuck | 222 Cognac Milled

Casual leather or nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned removeable Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole for greater comfort.

(006, 215) M 7-12, 13, 14 W 7-11, 12, 13 (222) M 7-12, 13, 14



010

## Norwalk Side Zip Boot | COMFORTECH

13393



215

### 010 Black Crazy Horse | 215 Brown Crazy Horse

Water-resisting casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned removeable Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 8-11, 12, 13



222

## Norwalk Plain Toe Chukka Boot | COMFORTECH

13370



010



215

### 222 Cognac Milled | 010 Black Crazy Horse | 215 Brown Crazy Horse

Casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned removeable Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort, lightweight and flexible TPU outsole for greater comfort.

M 7-12, 13, 14 W 7-11, 12, 13



## Highland Plain Toe Oxford

14272



221

### 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for all-day comfort, durable and cushioned EVA outsole with rubber heel for abrasion resistance.

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14

## Highland Canvas Plain Toe Oxford

14273



410



001

020

### 410 Navy | 001 Black | 020 Gray

Canvas with leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for long-term wearability, durable and cushioned EVA outsole with rubber heel for abrasion resistance.

M 7-12, 13, 14

## Dash Wingtip Oxford | COMFORTECH

11768



111



229

### 111 Black and White | 229 Cognac Smooth

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort and flexibility, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Forecast Plain Toe Slip On | COMFORTECH

12196



001

### 001 Black

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with Ortholite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning with slip-resisting and non-marking rubber traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

## Forecast Cap Toe Oxford | COMFORTECH

12191



001



221

### 001 Black | 221 Cognac

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with Ortholite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning with slip-resisting and non-marking rubber traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

---

## Forecast Plain Toe Oxford | COMFORTECH

12190



001



221

### 001 Black | 221 Cognac

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with Ortholite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning with slip-resisting and non-marking rubber traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

---

## Forecast Bike Toe Oxford | COMFORTECH

12188



001



221

### 001 Black | 221 Cognac

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with Ortholite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning with slip-resisting and non-marking rubber traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

---

## Forecast Bike Toe Slip On | COMFORTECH

12189



001

### 001 Black

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with Ortholite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning with slip-resisting and non-marking rubber traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13



## Midtown Plain Toe Oxford | COMFORTECH

12135



001



221

### 001 Black | 221 Cognac

Soft leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

## Midtown Moc Toe Oxford | COMFORTECH

12136



001

### 001 Black

Soft leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

## Midtown Wingtip Oxford | COMFORTECH

12139



221



001

### 221 Cognac | 001 Black

Soft leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

## Midtown Cap Toe Oxford | COMFORTECH

12138



221



001



200

### 221 Cognac | 001 Black | 200 Brown

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

(001, 221) B 9-11, 12, 13, 14 D 6-12, 13, 14, 15, 16, 17, 18 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13  
(200) D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15

## Midtown Bike Toe Slip On | COMFORTECH

12166



001

### 001 Black

Soft leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13, 14

## Midtown Penny Slip On | COMFORTECH

12159



221



001

### 221 Cognac | 001 Black

Soft leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

## Midtown Moc Toe Slip On | COMFORTECH

12137



001



221

### 001 Black | 221 Cognac

Soft leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

(001) B 9-11, 12, 13, 14 D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

(221) D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

## Midtown Plain Toe Zip Boot | COMFORTECH

12140



001



200



221

### 001 Black | 200 Brown | 221 Cognac

Soft leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15



## Rucci Weave Cap Toe Oxford

13407



221



001

### 221 Cognac | 001 Black

Smooth leather with weave print leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Rucci Weave Moc Toe Penny Loafer

13408



221



001

### 221 Cognac | 001 Black

Smooth leather with weave print leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Rucci Moc Toe Penny Loafer

13409



601



001



216



221



415

### 601 Burgundy | 001 Black | 216 Mocha Suede | 221 Cognac | 415 Navy Suede

Smooth leather or suede upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Rucci Plain Toe Oxford

13385



221



001

### 221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Rucci Wingtip Oxford

13383



221



001

200

**221 Cognac | 001 Black | 200 Brown**

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed for all-day comfort, rubber outsole offers durability, traction, and comfort.

(001, 221) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15 (200 ) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14

## Rucci Cap Toe Oxford

13384



001



221

200

**001 Black | 221 Cognac | 200 Brown**

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed for all-day comfort, rubber outsole offers durability, traction, and comfort.

(001, 221) M 7-12, 13, 14, 15, 16, 17, 18 W 7-11, 12, 13, 14, 15  
(200 ) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14

## Rucci Moc Toe Slip-on

13386



001



221

**001 Black | 221 Cognac**

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed for all-day comfort, rubber outsole offers durability, traction, and comfort.

(001) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15 (221) M 7-12, 13, 14 W 7-11, 12, 13





221

### Rucci Plain Toe Gore Boot

13403



001

#### 221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



200

### Rucci Plain Toe Chukka Boot

13392



001

#### 200 Brown | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



001

### Rucci Moc Toe Tassel Loafer

13402



221

#### 001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



001

### Zaffiro Moc Toe Bit Loafer

15209



221

#### 001 Black | 221 Cognac

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Zaffiro Cap Toe Oxford

15204



001



221

### 001 Black | 221 Cognac

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

---

## Zaffiro Moc Toe Oxford

15205



221



001

### 221 Cognac | 001 Black

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

---

## Zaffiro Moc Toe Venetian Loafer

15207



001



221

### 001 Black | 221 Cognac

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

---

## Zaffiro Moc Toe Penny Loafer

15206



221



001

### 221 Cognac | 001 Black

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

---



## Flex Plain Toe Oxford

14318



001



221

### 001 Black | 221 Cognac

Smooth leather upper, comfortable herringbone textile linings, fully cushioned footbed with Rebound EVA for all-day comfort and cushioning, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

---

## Flex Cap Toe Oxford

14317



221



001

### 221 Cognac | 001 Black

Smooth leather upper, comfortable herringbone textile linings, fully cushioned footbed with Rebound EVA for all-day comfort and cushioning, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

---

## Conetta Cap Toe Oxford

12197



001



221

### 001 Black | 221 Cognac

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned Memory Foam footbed with sheepskin leather cover for all-day comfort, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

---

## Conetta Wingtip Oxford

12198



221



001

### 221 Cognac | 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned Memory Foam footbed with sheepskin leather cover for all-day comfort, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

---

## Conetta Moc Toe Bit Slip On

12203



001

### 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned Memory Foam footbed with sheepskin leather cover for all-day comfort, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

## Conetta Moc Toe Venetian

12199



221



001

### 221 Cognac | 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned Memory Foam footbed with sheepskin leather cover for all-day comfort, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

## Conetta Bike Toe Oxford

12201



001

### 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned Memory Foam footbed with sheepskin leather cover for all-day comfort, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

## Conetta Bike Toe Slip On

12202



001

### 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole.

M 7-12, 13, 14 W 7-11, 12, 13



## Sorrento Cap Toe Oxford

14292



001



221

### 001 Black | 221 Cognac

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort, flexsole Technology for straight out-of-the-box comfort with no break-in time.

M 7-12, 13, 14 W 7-11, 12, 13

## Sorrento Wingtip Oxford

14291



221



001

### 221 Cognac | 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort, flexsole Technology for straight out-of-the-box comfort with no break-in time.

M 7-12, 13, 14 W 7-11, 12, 13

## Sorrento Plain Toe Single Monk Strap

14293



001



221

### 001 Black | 221 Cognac

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort, flexsole Technology for straight out-of-the-box comfort with no break-in time.

M 7-12, 13, 14 W 7-11, 12, 13

## Sorrento Moc Toe Penny Loafer

14294



221



001

### 221 Cognac | 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort, flexsole Technology for straight out-of-the-box comfort with no break-in time.

M 7-12, 13, 14 W 7-11, 12, 13

## Postino Cap Toe Oxford

15149



221



001



005

**221 Cognac Perf | 001 Black Perf | 005 Black Smooth**

Smooth or perf print leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

(001, 221) D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15 (005) D 7-12, 13, 14 3E 7-11, 12, 13

## Postino Plain Toe Oxford

15150



001



005



221

**001 Black Perf | 005 Black Smooth | 221 Cognac Perf**

Smooth or perf print leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

(001, 221) D 7-12, 13, 14 (005) D 7-12, 13, 14 3E 7-11, 12, 13

## Postino Cap Toe Bal Oxford

15175



225



001



005



221

**225 Cognac Smooth | 001 Black Scratch | 005 Black Smooth | 221 Cognac Scratch**

Smooth or scratch print leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

(005) D 6-12, 13, 14 (001, 221, 225) D 7-12, 13, 14



## Postino Moc Toe Oxford

15196



005

### 005 Black Smooth

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14 3E 7-11, 12, 13

## Postino Moc Toe Venetian Slip On

15176



221



001



005



225

### 221 Cognac Scratch | 001 Black Scratch | 005 Black Smooth | 225 Cognac Smooth

Smooth or scratch print leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

(001, 221, 225) D 7-12, 13, 14 (005) D 7-12, 13, 14 3E 7-11, 12, 13

## Postino Bike Toe Oxford

15154



005

### 005 Black Smooth

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14 3E 7-11, 12, 13

## Postino Bike Toe Slip On

15156



005

### 005 Black Smooth

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 6-12, 13, 14 3E 7-11, 12, 13

## Postino Plain Toe Bal Oxford

15195



005

### 005 Black Smooth

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14

---

## Corbetta Cap Toe Oxford

14180



221



001

### 221 Cognac | 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with leather cover for all-day comfort, durable rubber outsole.

D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15

---

## Amelio Moc Toe Venetian Slip On | COMFORTECH

14266



001

### 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned, removable footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Bologna construction for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

---

## Amelio Moc Toe Penny Loafer | COMFORTECH

14246



001

### 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned, removable footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Bologna construction for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13



## Tux Cap Toe Oxford

14213



004

### 004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with leather cover for all-day comfort, durable non-leather outsole.

D 7-12, 13, 14 3E 7-11, 12, 13, 14

---

## Tux Plain Toe Oxford

14212



004

### 004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with leather cover for all-day comfort, durable non-leather outsole.

D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15

---

## Postino Plain Toe Slip On

15178



004

### 004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 3E 7-12, 13, 14

---

## Postino Plain Toe Venetian Slip On

15208



410



001



601

### 410 Navy | 001 Black | 601 Burgundy

Striped velvet textile upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14

CLASSICS



**BERKLEY**  
Flex Penny  
Loafer



## Lexington Cap Toe Oxford

17067



01

### 01 Black

Smooth leather upper, manmade linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

(01) D 7-12, 13, 14, 15 3E 7-12, 13

## Lexington Wingtip Oxford

17066



01



05

### 01 Black | 05 Burgundy

Smooth leather upper, manmade linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

(01) D 7-12, 13, 14, 15 3E 7-12, 13 (05) D 7-12, 13, 14 3E 7-12, 13

## Lexington Wingtip Tassel Slip On

17073



01

### 01 Black

Smooth leather upper, manmade linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

D 7-12, 13, 14 3E 7-11, 12, 13

## Lexington Plain Toe Oxford

17079



01

### 01 Black

Smooth leather upper, manmade linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

D 7-12, 13 3E 7-12

## Dailey Cap Toe Oxford | COMFORTECH

17057



01

### 01 Black

Smooth leather upper, leather linings for added breathability, fully cushioned Comfortech footbed for long-term wearability, durable rubber outsole.

M 7-12, 13, 14 W 7-12, 13

## Como Moc Toe Strap Loafer

17089



01



18

### 01 Black | 18 Dark Cherry

Kidskin leather upper, leather linings for added breathability, durable leather outsole, genuine handsewn construction.

(01) B 9-12, 13, 14 D 6-12, 13, 14, 15 3E 6-12, 13, 14 (18) D 5-12, 13, 14 3E 6-12, 13

## Berkley Flex Penny Loafer

12195



963



005



215



229



601

### 963 Black/Brown | 005 Black Smooth | 215 Brown Crazy Horse | 229 Cognac Multi | 601 Burgundy

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with sheepskin cover for all-day comfort, durable and cushioned EVA sole with rubber heel and Flexsole Technology for out-of-the-box comfort, genuine handsewn construction.

B 9-12, 13 D 7-12, 13, 14 3E 7-12, 13, 14

## Berkley Moc Toe Penny Loafer

17058



01



05

### 01 Black | 05 Burgundy

Smooth leather upper, unlined shoe, cushioned heel for extra comfort, durable leather outsole, genuine handsewn construction.

B 9-12, 13, 14, 15, 16 D 6-12, 13, 14, 15, 16 E 7-11, 12 3E 6-12, 13, 14, 15, 16



## Noble Plain Toe Oxford | COMFORTECH

17080



01

### 01 Black

Smooth leather upper, leather linings for added breathability, fully cushioned, removable Comfortech footbed for long-term wearability, durable rubber outsole.

M 7.5-12, 13, 14 W 7-12, 13

---

## Riva Moc Toe Bit Loafer | COMFORTECH

17088



01



02



05

### 01 Black | 02 Brown | 05 Burgundy

Kidskin leather upper, leather linings for added breathability, elastic gore under the tongue for added comfort, fully cushioned Comfortech footbed for long-term wearability, lightweight and durable polyurethane outsole.

(01, 05) B 9-12, 13, 14, 15 D 6-12, 13, 14, 15 E 6-12, 13 3E 6-12, 13, 14 5E 6-12, 13, 14

(02) D 6-12, 13 3E 6-12, 13, 14, 15

---

## Pisa Moc Toe Tassel Loafer

18469



01



03

### 01 Black | 03 Cognac

Nappa leather and crocodile print leather upper, leather linings for added breathability, fully cushioned footbed for all-day comfort, durable non-leather sole, genuine handsewn construction.

D 7-12, 13, 14, 15, 16 3E 7-12, 13, 14, 15, 16



03

### Duke Bike Toe Zip Boot

17087



01

#### 03 Antique Gold | 01 Black

Kidskin leather upper, leather linings from the toe up through the shaft for added breathability, cushioned heeld for extra comfort, durable leather outsole.

(01) D 6-12, 13 E 8-11 3E 6-12, 13 (03) D 6-12, 13 3E 6.5-12, 13



18

### Essex Moc Toe Zip Boot

17074



01

#### 18 Dark Cherry | 01 Black

Kidskin leather upper, leather linings from the toe up through the shaft for added breathability, cushioned heeld for extra comfort, durable leather outsole.

(01) D 6-12, 13 3E 6-11, 12, 13 (18) D 6-12, 13 3E 6-11, 12



01

### Kenmoor Wingtip Oxford

17109



05

#### 01 Black | 05 Wine

Smooth or pebble grain calfskin leather upper, leather linings for added breathability, cushioned heeld for extra comfort, classic double leather outsole, Goodyear welt construction allows this shoe to be professionally resoled.

D 6-12, 13, 14 3E 6-12, 13



01

### Como Moc Toe Strap Loafer

17116

#### 01 Black

Nappa leather upper, leather linings for added breathability, elastic gore under the tongue for added comfort, cushioned heeld for extra comfort, buffed leather outsole.

D 5 1/2-12, 13, 14, 15 3E 6-12, 13, 14



SEASONAL



**RENEGADE**  
Plain Toe  
Chukka Boot

## Lookout Plain Toe Side Zip Boot | COMFORTECH

13405



007

### 007 Black Tumbled

Waterproof casual leather upper, thermal textile linings with 200 g Thinsulate™ insulating for warmth, fully cushioned Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort, waterproof construction.

M 7-12, 13, 14 W 7-11, 12, 13

## Lookout Moc Toe Lace Up Boot | COMFORTECH

13413



007

### 007 Black Tumbled

Waterproof casual leather upper, thermal textile linings with 200 g Thinsulate™ insulating for warmth, fully cushioned Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort, waterproof construction.

M 7-12, 13, 14 W 7-11, 12, 13

## Trail Mix Plain Toe Chukka Boot | COMFORTECH

14424



215



010



216

### 215 Brown Crazy Horse | 010 Black Crazy Horse | 216 Mocha Nubuck

Casual leather or nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA for long-term wearability, shock absorbing EVA midsole for utmost comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Cozy Moc Toe Tie Slipper | COMFORTECH

12184



269



061



202

### 269 Sand | 061 Gray | 202 Chocolate

Suede upper, soft, faux shearling linings for added warmth, fully cushioned, removable footbed with OrthoLite® high rebound foam, durable indoor/outdoor rubber sole.

M 8-13 (Whole sizes only) W 8-13 (Whole sizes only)





205

### Lodge Plain Toe Gore Boot

14285



010



215

**205 Chestnut Smooth | 010 Black Crazy Horse | 215 Brown Crazy Horse**

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14



010

### Lodge Plain Toe Chukka Boot

14284



205



215

**010 Black Crazy Horse | 205 Chestnut Smooth | 215 Brown Crazy Horse**

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14



215

### Lodge Cap Toe Lace Up Boot

14286



010



205

**215 Brown Crazy Horse | 010 Black Crazy Horse | 205 Chestnut**

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14



200

## Renegade Wingtip Lace Up Boot

15202



001



215

**200 Brown Smooth/Suede | 001 Black Smooth | 215 Brown Crazy Horse**

Smooth or casual leather upper, breathable Jersey textile linings, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole added cushioning and rebound responsiveness.

M 7-12, 13, 14



215

## Renegade Plain Toe Chukka Boot

15199



001



200

**215 Brown Crazy Horse | 001 Black Smooth | 200 Brown Smooth**

Smooth or casual leather upper, breathable Jersey textile linings, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole added cushioning and rebound responsiveness.

M 7-12, 13, 14



221

## Renegade Wingtip Oxford

15198



001

**221 Cognac | 001 Black**

Smooth or casual leather upper, breathable Jersey textile linings, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole added cushioning and rebound responsiveness.

M 7-12, 13, 14



001

## Renegade Plain Toe Gore Boot

15201



215



221

**001 Black Smooth | 215 Brown Crazy Horse | 221 Cognac Smooth**

Smooth or casual leather upper, breathable Jersey textile linings, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole added cushioning and rebound responsiveness.

M 7-12, 13, 14

STYLE	NAME	PAGE	5 - 5½	6 - 6½	15	16	17	18	B	N	E	5E	XW
12135	Midtown Plain Ox	13			X							X	
12137	Midtown Moc Slip	14			X				X			X	
12138	Midtown Cap Ox	13		X	X	X	X	X	X			X	
12140	Midtown Zip Boot	14			X	X							
12195	Berkley Flex Penny Loafer	28							X				
13157	Lakeside Moc Ox	4			X								X
13158	Lakeside Moc Slip	4			X								X
13368	Norwalk Cap Toe Ox	9			X								
13369	Norwalk Plain Toe Ox	9			X								
13383	Rucci Wingtip Ox	16			X								
13384	Rucci Cap Toe Ox	16			X	X	X	X					
13386	Rucci Moc Toe Slip On	16			X								
13401	Lakeside Canvas Moc Toe Slip On	4											X
14180	Corbetta Cap Ox	24			X	X							
14421	Crossover Moc Toe Slip On	3			X								
14272	Highland Plain Toe Oxford	11											
15149	Postino Cap Toe Oxford	22			X	X							
15156	Postino Bike Toe Slip On	23		X									
17058	Berkley Penny Loafer	28		X	X	X			X		X		
17066	Lexington Wingtip Ox	27			X								
17067	Lexington Cap Toe Ox	27			X								
17074	Essex Boot	30		X									
17087	Duke Boot	30		X							X		
17088	Riva Moc Slip	29		X	X				X		X	X	
17089	Como Moc Slip	28	X	X	X				X				
17109	Kenmoor Wingtip Ox	30		X									
17116	Como Imperial Moc Slip	30	X	X	X								
18469	Pisa Moc Slip	29			X	X							



# INDEX

11768 - Dash Wingtip Oxford.....	11	14318 - Flex Plain Toe Oxford.....	19
12135 - Midtown Plain Toe Oxford.....	13	14320 - Venture Fisherman Sandal.....	6
12136 - Midtown Moc Toe Oxford.....	13	14352 - Heist Lace to Toe Sneaker.....	2
12137 - Midtown Moc Toe Slip On.....	14	14354 - Heist Knit Lace to Toe Sneaker.....	2
12138 - Midtown Cap Toe Oxford.....	13	14362 - Tread Lite River Sandal.....	6
12139 - Midtown Wingtip Oxford.....	13	14363 - Tread Lite Thong Sandal.....	6
12140 - Midtown Plain Toe Zip Boot.....	14	14405 - Crossover Canvas Elastic Slip On.....	3
12159 - Midtown Penny Slip On.....	14	14417 - Vibe Wingtip Oxford.....	8
12166 - Midtown Bike Toe Slip On.....	14	14418 - Vibe Plain Toe Oxford.....	8
12184 - Cozy Moc Toe Tie Slipper.....	32	14419 - Vibe Canvas Plain Toe Oxford.....	8
12188 - Forecast Bike Toe Oxford.....	12	14420 - Vibe Knit Plain Toe Oxford.....	8
12189 - Forecast Bike Toe Slip On.....	12	14421 - Crossover Moc Toe Slip On.....	3
12190 - Forecast Plain Toe Oxford.....	12	14422 - Satellite Knit Elastic Lace Slip On Sneaker..	1
12191 - Forecast Cap Toe Oxford.....	12	14423 - Satellite Perf Lace Up Sneaker.....	1
12195 - Berkley Flex Penny Loafer.....	28	14424 - Trail Mix Plain Toe Chukka Boot.....	32
12196 - Forecast Plain Toe Slip On.....	11	14425 - Crossover Double Gore Slip On.....	3
12197 - Conetta Cap Toe Oxford.....	19	14426 - Crossover Moc Toe Elastic Lace Boat Shoe	4
12198 - Conetta Wingtip Oxford.....	19	14427 - Social Lace to Toe Sneaker.....	1
12199 - Conetta Moc Toe Venetian.....	20	14428 - Social Plain Toe Slip On Sneaker.....	1
12201 - Conetta Bike Toe Oxford.....	20	15149 - Postino Cap Toe Oxford.....	22
12202 - Conetta Bike Toe Slip On.....	20	15150 - Postino Plain Toe Oxford.....	22
12203 - Conetta Moc Toe Bit Slip On.....	20	15154 - Postino Bike Toe Oxford.....	23
13157 - Lakeside Moc Toe Oxford.....	4	15156 - Postino Bike Toe Slip On.....	23
13158 - Lakeside Moc Toe Slip On.....	4	15175 - Postino Cap Toe Bal Oxford.....	22
13367 - Atlantic Moc Toe Boat Shoe.....	5	15176 - Postino Moc Toe Venetian Slip On.....	23
13368 - Norwalk Cap Toe Oxford.....	9	15178 - Postino Plain Toe Slip On.....	25
13369 - Norwalk Plain Toe Oxford.....	9	15195 - Postino Plain Toe Bal Oxford.....	24
13370 - Norwalk Plain Toe Chukka Boot.....	10	15196 - Postino Moc Toe Oxford.....	23
13376 - Norwalk Plain Toe Lace Up Boot.....	10	15198 - Renegade Wingtip Oxford.....	34
13383 - Rucci Wingtip Oxford.....	16	15199 - Renegade Plain Toe Chukka Boot.....	34
13384 - Rucci Cap Toe Oxford.....	16	15201 - Renegade Plain Toe Gore Boot.....	34
13385 - Rucci Plain Toe Oxford.....	15	15202 - Renegade Wingtip Lace Up Boot.....	34
13386 - Rucci Moc Toe Slip-on.....	16	15204 - Zaffiro Cap Toe Oxford.....	18
13392 - Rucci Plain Toe Chukka Boot.....	17	15205 - Zaffiro Moc Toe Oxford.....	18
13393 - Norwalk Side Zip Boot.....	10	15206 - Zaffiro Moc Toe Penny Loafer.....	18
13401 - Lakeside Canvas Moc Toe Slip On.....	4	15207 - Zaffiro Moc Toe Venetian Loafer.....	18
13402 - Rucci Moc Toe Tassel Loafer.....	17	15208 - Postino Plain Toe Venetian Slip On.....	25
13403 - Rucci Plain Toe Gore Boot.....	17	15209 - Zaffiro Moc Toe Bit Loafer.....	17
13404 - Norwalk Moc Toe Slip On.....	9	17057 - Dailey Cap Toe Oxford.....	28
13405 - Lookout Plain Toe Side Zip Boot.....	32	17058 - Berkley Moc Toe Penny Loafer.....	28
13407 - Rucci Weave Cap Toe Oxford.....	15	17066 - Lexington Wingtip Oxford.....	27
13408 - Rucci Weave Moc Toe Penny Loafer.....	15	17067 - Lexington Cap Toe Oxford.....	27
13409 - Rucci Moc Toe Penny Loafer.....	15	17073 - Lexington Wingtip Tassel Slip On.....	27
13410 - Motor Moc Toe Penny Driver.....	5	17074 - Essex Moc Toe Zip Boot.....	30
13411 - Motor Moc Toe Bit Driver.....	5	17079 - Lexington Plain Toe Oxford.....	27
13412 - Motor Moc Toe Venetian Driver.....	5	17080 - Noble Plain Toe Oxford.....	29
13413 - Lookout Moc Toe Lace Up Boot.....	32	17087 - Duke Bike Toe Zip Boot.....	30
14180 - Corbetta Cap Toe Oxford.....	24	17088 - Riva Moc Toe Bit Loafer.....	29
14212 - Tux Plain Toe Oxford.....	25	17089 - Como Moc Toe Strap Loafer.....	28
14213 - Tux Cap Toe Oxford.....	25	17109 - Kenmoor Wingtip Oxford.....	30
14246 - Amelio Moc Toe Penny Loafer.....	24	17116 - Como Moc Toe Strap Loafer.....	30
14266 - Amelio Moc Toe Venetian Slip On.....	24	18469 - Pisa Moc Toe Tassel Loafer.....	29
14272 - Highland Plain Toe Oxford.....	11		
14273 - Highland Canvas Plain Toe Oxford.....	11		
14284 - Lodge Plain Toe Chukka Boot.....	33		
14285 - Lodge Plain Toe Gore Boot.....	33		
14286 - Lodge Cap Toe Lace Up Boot.....	33		
14291 - Sorrento Wingtip Oxford.....	21		
14292 - Sorrento Cap Toe Oxford.....	21		
14293 - Sorrento Plain Toe Single Monk Strap.....	21		
14294 - Sorrento Moc Toe Penny Loafer.....	21		
14307 - Crossover Lace to Toe Sneaker.....	3		
14315 - Venture Knit Plain Toe Lace Up Sneaker.....	2		
14317 - Flex Cap Toe Oxford.....	19		









**UNITED STATES**  
 333 W ESTABROOK BLVD.  
 GLENDALE, WI 53212  
 1.800.843.7463

**CANADA**  
 8205 MONTREAL TORONTO BLVD.  
 MONTREAL-WEST, QUEBEC  
 514.364.5444